

SAMCOM
TWO-WAY RADIO

CP-200

**Cost Effective
Portable Radio**



► ***Instruction Manual***

INTRODUCTION

The model CP-200 is a cost-effective communication tool meant for both first time and intermediate users. This compact and lightweight radio is equipped with the necessary features to ensure reliable communication at an affordable price, ideal for business operators who need the basic and short-range communications.

MAIN FEATURES

- Compact, lightweight but rugged design
- IP54 rating splash and dust proof
- 1700mAh Li-ion battery and life up to 48 hours
- 16 programmable channels
- 50 CTCSS tones & 210 DCS codes in TX and RX
- High/low output power selectable
- Built-in VOX for hands-free communications
- Voice prompt
- Roger beep
- Monitor function
- Channels scan
- Battery saver
- Emergency alarm
- Time-out timer
- Busy channel lock-out
- PC programmable

CONTENTS

01 Chapter 1: SAFETY INFORMATION

01 Radio Care

01 Battery Care

03 Chapter 2: RADIO OVERVIEW

03 Package Includes

03 At a Glance

06 Chapter 3: BASIC OPERATION

06 Turn the Radio ON/OFF

06 Adjusting Volume

06 Channel Selection

06 Transmission and Reception

07 Chapter 4: ADVANCED OPERATION

07 Monitor

07 Scanning Channels

07 Battery Save

07 VOX

08 Chapter 5: TROUBLESHOOTING

09 Chapter 6: SPECIFICATIONS

10 Chapter 7: WARRANTY INFORMATION

SAFETY INFORMATION

Please read this information before using your radio. Failure to do so could result in personal injury, death, and/or damage to your radio, accessories and/or other property.

Radio Care

Caution

- Do not disassemble or modify the radio for any reason.
- Do not transmit while touching the antenna terminal or any exposed metallic parts of the aerial as this may result in burn.
- Please check and observe regulation in your country with regards to use whilst driving.

End of Life Disposal

When your radio reaches the end of its useful life, please ensure that the unit is disposed of in an environmentally friendly way.

Battery Care

Precautions

- Turn the radio OFF before charging.
- Charge the battery pack before use.
- Do not recharge the battery pack if it is already fully charged as this will use one of its charge cycles and may shorten its life. Charge the battery in accordance with the instructions enclosed with your charger.
- Do not charge the radio and battery pack if they are wet.

The battery pack includes potentially hazardous components. Please:

- Do not disassemble or reconstruct battery.

- Do not short-circuit the battery.
- Do not incinerate or apply heat to the battery.
- Do not immerse the battery in water or get it wet by other means.
- Do not charge the battery near fires or under direct sunlight.
- Use only the specified charger and observe charging requirements.
- Do not pierce the battery with any object or strike it with an instrument.
- Do not use the battery pack if it is damaged in any way.
- Do not reverse-charge or reverse-connect the battery.
- Do not touch a ruptured or leaking battery.

If liquids from the battery get on your skin or into your eyes, immediately:

- Wash your eyes out with fresh water avoiding rubbing them.
- Seek medical treatment.

Notes:

- If a battery is not to be used for an extended period of time (several months) remove the battery pack from the equipment and store in a cool and dry location part charged. Do not fully discharge the battery before storage.
- Each charge cycle reduces the battery's life. Minimize the number of times you charge your battery especially in hotter environments which further shorten a battery's life.

RADIO OVERVIEW

Package Includes

1pcs radio

1pcs rubber antenna


1pcs rechargeable Lithium-ion battery pack

1pcs desktop charger kit

1pcs belt clip & hand strap

1pcs user's manual

At a Glance



1 - Antenna

Provide attached SMA rubber flexible antenna.

Note: It may cause the damage to your radio if the antenna is connected inappropriately.

2 - On / Off / Volume Knob

Turn the radio ON or OFF and to adjust the radio's volume.

3 – Channel Selector Knob

Select the radio's different channels.

4 - LED Indicator

Give radio transmit, receive, battery and other status.

Radio Status	LED Indicator
Transmit (TX)	Solid red
Receive (RX) & Monitor	Solid green
PC programming / Reading data	Green heartbeat
PC programming / Writing data	Red heartbeat
Channel scanning	Green heartbeat
Low battery	Red heartbeat

5 - PTT (Push-To-Talk) Button

Press and hold down this button to transmit and talk, release it to receive and listen.

6 - Side Button P1

The button **P1** is a general button that can be configured by the programming software. The default setting is '**Monitor**' feature.

7 - Side Button P2

The button **P2** is a general button that can be configured by the programming software. The default setting is '**Scan**' feature.

8 - Built-in Microphone

Speak clearly into the microphone when transmitting.

9 - Built-in Speaker

10 - Audio Accessory Jack (Kenwood 2 Pin Connector)

Connect compatible audio accessories, such as microphones earpieces, etc

11 - Rechargeable Li-ion Battery Pack

BASIC OPERATION

Turn the Radio ON / OFF

To turn on the radio, rotate on the On/Off/Volume Knob clockwise. The radio plays power up audio and channel number. To turn off the radio, rotate the On/Off/Volume Knob counterclockwise until you hear a 'Click' sound.

Adjusting Volume

Turn the On/Off/Volume Knob clockwise to increase the volume, or counterclockwise to decrease the volume.

Note: Do not hold the radio too close to the ear when the volume is high or when adjusting the volume.

Channel Selection

To select a channel, turn the Channel Selector Knob until you reach the desired channel. An audible voice indicates the selected channel if the voice prompt is enable. Each channel has its own frequency, privacy code and other settings.

Transmission and Reception

1. Make sure that no one else is currently talking on the selected channel.
2. Keep **PTT** button firmly pressed.
3. Speak normally in the direction of the microphone.
4. When you have finished, release the **PTT**.
5. When the radio is in reception mode (**PTT** not pressed) you will automatically receive any communication.

Note: during transmission and reception, as far as possible, try to keep the antenna in vertical position and to avoid obstacles towards the direction of the other party.

ADVANCED OPERATON

Monitor

The Monitor feature is for temporarily opening the squelch in order to listen to signals that are too weak to open the squelch. By opening the squelch you will listen the communication “chopped” by the squelch. In order to activate the Monitor function, so as to listen to **all** traffic on the selected channel, Short press the side button **P1** once. Short press it again to disable this function.

Scanning Channels

The radio can automatically search for signals throughout the bands by scanning, i.e. selecting the channels in sequence. Short press the side button **P2** to start scanning. When a signal is detected, the scanning pauses on that channel and you can transmit by pressing **PTT** button. If you want to stop it, short press the side button **P2** again. The radio will go back to the channel from which the scanning originally started.

Battery Save

The battery saving feature enables a reduction in the consumption of up to 50%. Battery saving comes on automatically when the radio does not receive any signal for more than 5 seconds. When the batteries are discharged, replace the batteries or recharge the battery pack.

VOX Function

The VOX feature enables hands free conversations without using **PTT**, just speak in the direction of the microphone and the communication will be automatically activated. The VOX sensitivity can be adjusted in 10 different levels.

TROUBLESHOOTING

Problem	Possible Reasons and Potential Solutions
No Power	Recharge or replace the battery pack; Extreme operating temperatures may affect battery life.
Hearing other noises or conversation on a channel	Confirm CTCSS/DCS is set; Frequency or CTCSS/DCS may be in use; Change settings: either change frequencies or CTCSS/DCS on all radios; Make sure the radio is at the right frequency and privacy code when transmitting.
Audio quality not good enough	Radio settings might not be matching up correctly. Double check frequencies, CTCSS/DCS and bandwidths to make sure they are identical in all radios.
Limited talk range	Steel and/or concrete structures, heavy foliage, buildings or vehicles decrease range. Check for clear line of sight to improve transmission; Wearing radio close to body such as in a pocket or on a belt decreases range; Change location of radio. UHF radios provide great coverage in industrial and commercial buildings. Increasing power provides greater signal range and increases penetration through obstructions.
Can not transmitted or received	Make sure the PTT button is completely pressed when transmitting; Confirm that the radios have the same channel, frequency, private code and bandwidth settings; Recharge, replace and/or reposition batteries; Obstructions and operating indoors, or in vehicles, may interfere, change location; Verify that the radio is not in Scan.
Heavy static or interference	Radios are too close, they must be at least seven feet apart; Radios are too far apart or obstacles are interfering with transmission.
Low battery	Recharge or replace the battery pack; Extreme operating temperatures affect battery life.
Desktop Charger LED light does not blink	Check that the radio/battery is properly inserted and check the battery/charger contacts to ensure that they are clean and charging pin is inserted correctly.
Cannot activate VOX	VOX feature might be set to OFF; Use the programming software to ensure that the VOX sensitivity level is not set to '0'; Accessory not working or not compatible.
Battery does not charge	Check desktop charger is properly connected and correspond to a compatible AC adapter; Check the charger's LED indicators to see if the battery has a problem.

SPECIFICATIONS

General

Frequency Range	UHF: 433 / 446 / 400-480MHz
Channel Capacity	16 Channels
Channel Bandwidth	12.5 / 25kHz
Operating Voltage	3.7V DC
Dimensions (H x W x D)	98 x 55 x 30mm
Weight with battery	170g

Transmitter

RF Power(H/L)	Low: 500mW / High: 2W
Frequency Stability	$\pm 1.5\text{ppm}$
Spurious & Harmonics	-36dBm < 1GHz -30dBm > 1GHz
FM Hum & Noise	$\geq 40\text{dB(W)} / \geq 36\text{dB(N)}$
Modulation Deviation	$\leq 5\text{kHz(W)} / \leq 2.5\text{kHz(N)}$
Adjacent Channel Power	$\geq 70\text{dBC(W)} / \geq 60\text{dBC(N)}$
Audio Frequency Response	+1 ~ -3dB
Audio Distortion	< 5%

Receiver

Sensitivity (12 dB SINAD)	$\leq 0.2\mu\text{V(W)} / \leq 0.3\mu\text{V(N)}$
Adjacent Channel Selectivity	$\geq 70\text{dBC(W)} / \geq 60\text{dBC(N)}$
Audio Distortion	< 5%
Radiated Spurious Emissions	< -54dBm
Intermodulation Rejection	70dB
Audio Output	1W @ 8 Ω

Hereby, we declare that our radio is in compliance with the essential requirements and other relevant provisions of RE Directive 2014/53/EU.

WARRANTY INFORMATION

Warranty Period

Radio Body: 12 months from date of purchase.

Battery Pack: 6 months from date of purchase.

Note: Please retain your receipt as your proof of purchase will be required to valid warranty claim.




Warranty Exclusions

This warranty will not apply in relation to:

- Failure to provide a proof of purchase
- Product has been modified, changed or serial number has been removed
- If any damage is caused by the use of non approved accessories
- Product that has been replaced by an unauthorized person
- Product failure due to customer misuse, abuse or abnormal use
- Failure by the customer to take reasonable care
- Failure due to not using the product in accordance with instructions stated in the manufacture's user guide.
- Product failure due to recommended installation procedures not being followed as stated in the manufacture's user guide.

More warranty relative information please read our Warranty Policy on the website.

SAMCOM

 www.samradios.com  +86-595-86713710  info@samradios.com

MADE IN CHINA